


Sentry[™]

Remote Monitoring and Control System

User Guide





Thank you for purchasing SureCall's Sentry remote monitoring system. The Sentry provides seamless installation, optimization and ongoing management of SureCall's line of boosters. If you need any assistance during installation please contact our tech support department at: 1-888-365-6283.

Sentry is compatible with the following SureCall products:

- Force5
- Fusion5s
- Guardian3
- Force7

Package Contents	4
Installation Overview	5-6
Sentry Registration	7
Adding Booster	8-9
Antenna Placement Tool	10-11
Configure Gain Settings	12-13
Changing Booster Information	14
Delete Booster	15
Modify Password	16
Archiving Booster Information	17
Specifications	18

Package Contents

Your Sentry hardware kit includes the following:

- Sentry Product
- Ribbon Cable
- USB Cable
- AC Adapter

Sentry



Ribbon Cable




AC Adapter



USB Cable






Sentry Hardware Installation

- Step 1: Connect the ribbon cable (provided) from the Sentry's 14-Pin RF port to the booster's 14-Pin RF port.
- Step 2: Connect the USB cable (provided) to the Sentry's USB port then connect the other end of the USB cable to the USB port on your computer.
- Step 3: Connect a LAN cable to the Sentry's LAN port and connect the other end to your router.
- Step 4: Connect the AC adapter cord to the Sentry's Power port with the other end plugged into an electrical outlet.

Sentry Software Installation

Sentry Operation

User Registration:



The screenshot displays the login and registration interface for the Sentry Remote Monitoring and Control System. The title "Sentry Remote Monitoring and Control System" is centered at the top in a blue font. Below the title, there are two input fields: "Username" and "Password". To the right of the "Password" field is a green "Login" button. Below the "Password" field is a link that says "Forgot your password?". At the bottom of the form area, there are two green buttons: "Exit" and "Register". Below the buttons, the text "(Version:V1.0)" is displayed.

Click on the Register Button

Sentry Registration

Step 1: Download the software at www.surecall.com/product/Sentry.html

Step 2: Install the software on the computer that you will be using for remote monitoring. Run as admin.

Step 3: Enter SureCall's Server IP address, 99.55.251.45 in the Registration Window.

Step 4: Fill in the User Registration form and choose a user name, password, email and user phone. Once completed, click the Register button.

Step 5: Login to Sentry



The screenshot shows the 'Sentry Remote Monitoring and Control System' login interface. It features the SureCall logo at the top left. Below the title, there are input fields for 'Username' and 'Password', followed by a green 'Login' button. A link for 'Forgot your password?' is also present. To the right, there is a 'Server Ip' field containing '99.55.251.45'. At the bottom, there are three buttons: 'Exit', 'Register', and 'User Registration'. The version '(Version:V1.0)' is displayed at the bottom center.



The screenshot shows a 'User Registration' dialog box with a close button in the top right corner. It contains five input fields: 'User Name', 'Password', 'Confirm Password', 'E-mail', and 'User Phone'. A blue 'Register' button is located at the bottom right of the form.



The screenshot shows the 'Sentry Remote Monitoring and Control System' login interface, similar to the first screenshot. It features the SureCall logo at the top left. Below the title, there are input fields for 'Username' and 'Password', followed by a green 'Login' button. A link for 'Forgot your password?' is also present. At the bottom, there are two buttons: 'Exit' and 'Register'. The version '(Version:V1.0)' is displayed at the bottom center.

Adding Booster

The screenshot shows a dialog box titled "Add Booster (one booster per Sentry)". It contains the following fields and controls:

- Com Port: A dropdown menu with an "Open" button and a "Close" button.
- Server IP Address: A text field with a dropdown arrow.
- Server Port Number: A text field with a dropdown arrow.
- Auto Search IP: A checkbox.
- Sentry IP: A text field.
- Sentry Subnet Mask: A text field.
- Sentry Default Gateway: A text field.
- Refresh: A button.
- Apply: A button.
- Sentry ID Code: A text field.
- Booster Name: A text field.
- Location Address: A text field with a vertical scrollbar.
- Add: A button.

Select Com Port and Open

Click "Refresh" to automatically assign the IP address to the Sentry.

Server IP Address will automatically enter 99.55.251.45 Click on "Apply"

Enter a Booster Name and Location Address and click on the "Add" button to add a booster

Adding a Booster

Add Booster (one booster per Sentry)

Com Port: COM10

Server IP Address: 99.55.251.45

Server Port Number: 5210

Auto Search IP

Sentry IP: 192.168.1.20

Sentry Subnet Mask: 255.255.255.0

Sentry Default Gateway: 192.168.1.1

Refresh Apply

Sentry ID Code: 63FF7D501465233384740234

Booster Name: Force-7

Location Address: [Empty]

Add

When a booster is connected to Sentry, it will automatically identify the model of the booster and show the corresponding interface.

See example next page

Antenna Placement Tool

Force5

Add Booster

Force-5

Type: Force5 Name: Force-5 Address: Address

Band	Channel	Attenuation	Manual Attenuation	Automatic Gain Control Attenuation	Gain	Output Power	Outside Signal Strength	Uplink/Downlink Status	Band On/Off	Over Power	Oscillation	Over Attenuation
LTE-A	Uplink 698-716M	0 dB	0 dB	0 dB	64 dB	-20 dBm		Active	ON	Normal	Normal	Normal
	Downlink 728-746M	0 dB	0 dB	0 dB	64 dB		-75 dBm	ON	ON	Normal	Normal	Normal
LTE-V	Uplink 776-792M	0 dB	0 dB	0 dB	64 dB	-20 dBm		Active	ON	Normal	Normal	Normal
	Downlink 746-757M	0 dB	0 dB	0 dB	64 dB		-75 dBm	ON	ON	Normal	Normal	Normal
Cellular	Uplink 824-849M	0 dB	0 dB	0 dB	65 dB	-15 dBm		Active	ON	Normal	Normal	Normal
	Downlink 869-894M	0 dB	0 dB	0 dB	65 dB		-75 dBm	ON	ON	Normal	Normal	Normal
PCS	Uplink 1850-1915M	0 dB	0 dB	13 dB	59 dB	-20 dBm		Active	ON	Normal	Normal	Normal
	Downlink 1930-1995M	0 dB	0 dB	4 dB	68 dB		-63 dBm	ON	ON	Normal	Normal	Normal
AWS	Uplink 1720-1755M	0 dB	0 dB	3 dB	68 dB	-17 dBm		Active	ON	Normal	Normal	Normal
	Downlink 2110-2155M	0 dB	0 dB	0 dB	71 dB		-67 dBm	ON	ON	Normal	Normal	Normal

Refresh Apply Sentry Software Version SC ME1-MONITOR V1.6 Connection Status Normal


Total Data: 1 Data Sent: 1 Data Received: 1

On the main interface screen, select the booster located in the left column, this will automatically populate the fields with the booster's parameters.

Antenna Placement Tool

This tool aids the installer in locating the best location for an outside antenna.

To test for the best location, make sure the outside antenna cable is connected to the booster and outdoor antenna. Place the antenna in a position you'd like to test and click on the measure button.



Antenna Position Debug Tool

Booster: Guardian 3


Position	Outside Signal Strength				Query Time	Operate
	LTE-A	LTE-V	Cellular	PCS		
Position1						Measure
Position2	-76dBm	-70dBm	-68dBm	-67dBm	09:52:35	Measure
Position3	-70dBm	-69dBm	-68dBm	-66dBm	09:52:37	Measure
Position4						Measure
Position5	-68dBm	-70dBm	-68dBm	-67dBm	09:52:43	Measure

The Best Position is Position5

This tool will identify the optimum location for the outdoor antenna. The “Position” fields will automatically populate with the dB measurement from various locations by clicking on the measure button at each possible location. You can test up to 5 positions. Once you have entered all locations, click on the “Compare” button to find the best location. Keep in mind that a signal of less than -65 dB can over-power the booster. Aim for a range of -70 to -90 dB. The signal strength can be adjusted to a weaker signal by:

- Moving the outside antenna to a different location
- Adding an inline attenuator to the cable connecting to the booster
- Lowering the dB gain with the dip switches or dial knobs on the booster or through the Attenuation column in the Sentry software

Configure Gain Settings



Antenna Position Debug Tool

Booster: Force-5

Position	Outside Signal Strength					Query Time	Operate
	LTE-A	LTE-V	Cellular	PCS	AWS		
Position1	-56dBm	-64dBm	-44dBm	-49dBm	-49dBm	14:06:47	Measure
Position2	-64dBm	-69dBm	-48dBm	-51dBm	-51dBm	14:07:28	Measure
Position3	-66dBm	-72dBm	-53dBm	-59dBm	-59dBm	14:08:21	Measure
Position4	-73dBm	-75dBm	-57dBm	-65dBm	-65dBm	14:09:05	Measure
Position5	-75dBm	-75dBm	-63dBm	-67dBm	-67dBm	14:09:58	Measure

The Best Position is Position3

Attenuation:

If the “Over Power” alert is red, the signal coming into the booster from the cellular tower is too strong which will shut down the affected band. There are three possible solutions:

1. Add an inline attenuator to the cable coming into the booster
2. Relocate the outdoor antenna to a location where the signal is weaker
3. Lower the dB gain in 5 dB increments on the Sentry booster dashboard under the Attenuation column until the Over Power alert is no longer red.

Configure Gain Settings

Sentry Remote Monitoring and Control System(V1.3)

Tools

Add Booster

Type: Fusion5 Name: Fusion5s Address:

Band	Channel	Attenuation	Manual Attenuation	Automatic Gain Control Attenuation	Gain	Output Power	Outside Signal Strength	Uplink/Downlink Status	Band On/Off	Over Power	Oscillation	Over Attenuation
LTE-A	Uplink 698-716M	0 dB	0 dB	23 dB	41 dB	-14 dBm		OFF	ON	Normal	Normal	Normal
	Downlink 728-746M	0 dB	0 dB	15 dB	49 dB		-45 dBm	OFF	ON	Alert	Normal	Normal
LTE-V	Uplink 776-787M	0 dB	0 dB	23 dB	41 dB	-11 dBm		OFF	ON	Normal	Normal	Normal
	Downlink 746-757M	0 dB	0 dB	15 dB	49 dB		-45 dBm	OFF	ON	Alert	Normal	Normal
Cellular	Uplink 824-849M	0 dB	0 dB	15 dB	50 dB	-13 dBm		Sleep	ON	Normal	Normal	Normal
	Downlink 869-894M	0 dB	0 dB	9 dB	56 dB		-53 dBm	ON	ON	Normal	Normal	Normal
PCS	Uplink 1850-1910M	0 dB	0 dB	25 dB	47 dB	-15 dBm		OFF	ON	Alert	Normal	Normal
	Downlink 1930-1990M	0 dB	0 dB	20 dB	52 dB		-40 dBm	OFF	ON	Alert	Normal	Normal
AWS	Uplink 1710-1755M	0 dB	0 dB	25 dB	46 dB	-20 dBm		OFF	ON	Alert	Normal	Normal
	Downlink 2110-2155M	0 dB	0 dB	20 dB	51 dB		-46 dBm	OFF	ON	Alert	Normal	Normal

Refresh Apply

Sentry Software Version SC ME1-MONITOR V1.9 Connection Status Normal

Total Data: 1 Data Sent: 1 Data Received: 1

From the dashboard above you can manually adjust the attenuation dB to resolve problems with oscillation and overpowering issues. You can also turn off individual bands.

Column Definitions:

Attenuation: Adjusts the amount of gain reduction.

Manual Attenuation: Indicates the reduced gain through the booster's dip switches or dial knobs.

Automatic Gain Control: Indicates when the booster is automatically reducing the gain due to a strong outdoor signal or close indoor/outdoor antenna proximity.

Gain: Indicates the current gain on the amplifier.

Output Power: Indicates the power output level of the booster in dBm.

Uplink/Downlink Status: Indicates whether a band is asleep, turned on or turned off.

WARNING: Attenuation can be lowered to a maximum of 30 or 31 dB, depending on the booster model . Through the Sentry software the maximum attenuation is 25 dB.

Changing Booster Information



LED Color	Appearance	Indication
Red	Solid	Band is turned off or has been over-attenuated
Red	Flashing	Signal coming into booster from cellular tower is too strong causing the affected band to shut down. There are two possible solutions: 1. Add an inline attenuator to the cable coming into the booster. 2. Relocate the outdoor antenna to a location where the signal is weaker
Yellow	Flashing	Automatic Gain Control (AGC) is adjusting, part of normal operation.
Yellow	Solid	Indicates an inactive band, part of normal operation.
Yellow/Red	Alternately Flashing	Oscillation is detected. First try increasing the separation between the indoor and outdoor antennas. If this doesn't eliminate oscillation, lower the dB gain in 5 dB increments
Green	Solid	Booster is on.

Email Alerts

Email alerts will be sent in the event of booster overpowering, over-attenuation, or if oscillation is detected.



Changing your Booster Information

If you wish to change your Booster information, click on Edit Booster Info within the left hand navigation



Delete Booster


If you wish to delete a booster in order to add a new one, right click on the specific booster in the left hand navigational field first, then click on “Delete Booster” within the navigation window, click on and confirm the deletion. See below.



Modify your Password


Forget your Password?

On the login page, type in the email address that you entered when you first registered and click on “Forgot your Password”. Your password will be emailed to you.




Modifying your password:

To change your password, choose Tools in the top navigation and select the Accounts menu and select Modify Password/E-mail from the drop-down menu.




Enter the Old Password, choose a new password, confirm the new password and click on modify.

A "Modify Password/E-mail" form window. It contains the following fields: "User Name" with the value "surecall"; "Old Password" (empty); "New Password" (empty); "Confirm Password" (empty); "Old E-mail" with the value "anthony@surecall.com"; and "New E-mail" (empty). There are two "Modify" buttons, one at the bottom center and one to the right of the "New E-mail" field.

Archiving Booster Information

To temporarily change boosters, choose Tool in the top navigation and select “Booster Recycle Bin”. Information for this booster will be saved. Should you like to switch back to this booster or delete it, go back to “Booster Recycle Bin” where you will be given the option to restore or delete the booster.



A screenshot of a window titled 'Booster Recycle Bin'. The window contains a table with four columns: 'Booster Name', 'Sentry ID Code', 'Location Address', and 'Delete Time'. The table lists several boosters, with the last row, 'cm2020', selected. A context menu is open over the selected row, showing 'Restore' and 'Delete' options.

Booster Name	Sentry ID Code	Location Address	Delete Time
slow to	63FF3D501465233384250234	auto	2015-02-06 09:40:10
force5 recog	63FF6D501465233394520234		2015-02-06 09:40:14
z3581	83FF8D501485634323738034	auto obtain address	2015-02-06 09:40:19
z3026	83FF9D501485634353058034	192.168.1.250	2015-02-06 09:40:24
z3582	83FF8D501485634384420134	192.168.1.230	2015-02-06 09:40:34
z1501	B30046002115431323536353	.1.200	2015-02-06 09:40:38
z0730	83FF9D501485634364040134	auto	2015-02-06 09:40:42
z0918	83FF9D501485634353443134	auto	2015-02-06 09:40:45
cm2020	63FF7D501465233384740234		2015-02-06 09:40:50

Specifications

Model Name

Sentry

Uplink Frequency Range (MHz):	698-716 / 776-787 / 824-849 1850-1915 / 1710-1755 (G Block Included) PSB: 788-805 / 806-824 / 896-901
Downlink Frequency Range (MHz):	728-746 / 746-757 / 869-894 1930-1995 / 2110-2155 (G Block Included) PSB: 758-775 / 851-869 / 935-940
AC Power Transmitter:	Input AC 110 V, 60 Hz / Output DC 6V
Dimensions:	10-1/4 x 4-1/4 x 1-5/8 inches
Weight:	3.8 Lb



