



Scan for full manual

## SL-1N Quick Start Guide


This guide helps you install and use your SL-1N for the first time.

Go to [www.kramerav.com/downloads/SL-1N](http://www.kramerav.com/downloads/SL-1N) to download the latest user manual and check if firmware upgrades are available.

### Step 1: Check what's in the box

- ✓ SL-1N Master Room Controller
- ✓ Kramer RC-IR3 Infrared Remote Control Transmitter with batteries and user manual
- ✓ 1 Power supply (12V DC)
- ✓ 4 Rubber feet
- ✓ 1 Quick start guide

### Step 2: Get to know your SL-1N




#	Feature	Function
1	RELAYS Terminal Blocks	Connect to low-voltage relay-driven devices (from 1 to 3)
2	IR Output Terminal Blocks	Connect to IR emitter cables (from 1 to 2)
3	RS-232 Terminal Blocks	Connect to the RS-232 devices (from 1 to 2)
4	ETHERNET RJ-45 Connector	Connects to the PC or other serial controller through computer networking LAN
5	DEFAULT Pushbutton	Press to reset to factory default definitions: IP number – 192.168.1.39, mask – 255.255.0.0, gateway – 0.0.0.0, also to remove the current configuration First disconnect the power cord and then connect it again while pressing the ETH Factory Reset button. The unit powers up and loads its memory with the factory default definitions and erases all stored presets
6	K-NET Terminal Block	PIN GND is for the ground connection; PIN B (-) and PIN A (+) are for RS-485, and PIN +12V is for powering the unit The ground connection is sometimes connected to the shield of the RS-485 cable
7	12V DC Connector	For supplying power to the unit
8	IR IN Sensor and LED	Accepts IR remote commands
9	IR INPUT 3.5mm Mini Jack	Connects to a remote infrared sensor
10	NET LED	Illuminates while transmitting over Ethernet
11	K-NET LED	Illuminates when the K-NET is active (red – transmit, green – receive, during normal activity flashes red)
12	RS-232 Tx/Rx LEDs	Illuminates while transmitting/receiving on an RS-232 port (1 to 2) (red – transmit, green – receive)
13	IR LEDs	Illuminates when an IR port is active
14	RELAYS LEDs	Illuminates when a relay is active (1 to 3)
15	SRVC DIP-Switch	Slides down for service use only, slides up for normal operation
16	K-NET TERM DIP-Switch	Slides down for K-NET termination, slides up for not terminated
17	PROGRAM USB Connector	Connect to a computer for unit configuration and firmware upgrading

## Step 3: Mount SL-1N

Install SL-1N using one of the following methods:


- Attach the rubber feet and place the unit on a flat surface.
- Fasten a bracket on each side of the unit and attach it to a flat surface (see [www.kramerav.com/downloads/SL-1N](http://www.kramerav.com/downloads/SL-1N)).
- Mount the unit in a rack using the recommended rack adapter (see [www.kramerav.com/product/SL-1N](http://www.kramerav.com/product/SL-1N)).



- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.
- Reliable earthing of rack-mounted equipment should be maintained.

## Step 4: Connect inputs and outputs

Always switch OFF the power on each device before connecting it to your SL-1N.



To achieve specified extension distances, use the recommended Kramer cables available at [www.kramerav.com/product/SL-1N](http://www.kramerav.com/product/SL-1N). Using third-party cables may cause damage!

## Step 5: Connect power

Connect the power cord to SL-1N and plug it into the mains electricity.

Safety Instructions (See [www.kramerav.com](http://www.kramerav.com) for updated safety information)

### Caution:

- For products with relay terminals and GPIO ports, please refer to the permitted rating for an external connection, located next to the terminal or in the User Manual.
- There are no operator serviceable parts inside the unit.

### Warning:

- Use only the power cord that is supplied with the unit.
- Disconnect the power and unplug the unit from the wall before installing.

## Step 6: Operate SL-1N

Operate via the RC keypad, IR remote control, K-NET or Ethernet