


## 70V Multi-Zone Audio System:

- Multiple zone audio system with cascading amps
- Mic ducking occurs in all zones
- Discrete volume control for each zone



### System Notes

1. First amp handles mixing, mic ducking, and level controls for entire system.
2. Master Volume knob on each amp will change level on speakers connected to that amp but not the level going to the other amps.
3. For global volume adjustments, the master volume knob on each amp will need to be adjusted to the same level. Or, the Input Gain (such as Mic or Source) on the first amp can be adjusted and will adjust the level going to all amps.
4. Select Source 1 for all cascaded amps and open the Source Gain adjustment wide open (full gain).
5. Pre-Amp Output not typically used in this application. If jumper is removed between the mono RCA connectors, the powered speaker output to the local speakers will be disconnected.