

C4 CONTROLLER SETUP

CONTACTING TECH SUPPORT


Phone: 866.838.5052 704.909.5229

Email: TechSupport@SnapAV.com


HOW TO DISCOVER

1. Load the current version of **Composer**.
2. After Composer is loaded, browse to the **Discover** tab on the upper right-hand side of the screen.

NOTE: Auto-discovered devices appear in this section using SDDP protocol.



3. Double click the discovered device to add it to the project.
4. See the screenshot below for an example of how successfully added devices appear in the project.



MAKING THE CONNECTIONS

1. Bind the Tx and Rx to the source and display after the device has been added to the project.
2. Select **Connections** on the bottom left of the screen.
3. Bind the Tx first. Select **Tx 1** and drag it to the **HDMI Output Devices** list at the bottom of the screen.

See example:

Composer 2.10.1 - (Local)

File Driver Go Tools Help

Connections

Control/AV Network

New Project

- Home
 - House
 - Main
 - Master
 - WB-700-IPV-12
 - Luma IP Camera
 - SunBriteTV IR Veranda 43/55/74
 - XBOX One
 - Laptop PC
 - Luma IP Camera PTZ
 - Luma IP Camera 2
 - Luma IP Camera Fisheye
 - Home Controller HC800
 - Digital Media
 - Tuneln
 - My Music
 - My Movies
 - Stations
 - Channels
 - Binary MoIP Controller 2
 - Luma IP Camera 3
 - HouseLogix Test

Advanced Lighting

Control & Audio Video Connections

Binary MoIP Controller 2

Name	Type	Connection
Audio/Video Inputs		
TX 1	Video	HDMI Input XBOX One->HDMI Out
TX 2	Video	HDMI Input Laptop PC->AV Out
TX 3	Video	HDMI Input
TX 4	Video	HDMI Input
TX 5	Video	HDMI Input
TX 6	Video	HDMI Input
TX 7	Video	HDMI Input
TX 8	Video	HDMI Input
TX 9	Video	HDMI Input
TX 10	Video	HDMI Input
TX 11	Video	HDMI Input
TX 12	Video	HDMI Input
TX 13	Video	HDMI Input
TX 14	Video	HDMI Input
TX 15	Video	HDMI Input
TX 16	Video	HDMI Input
TX 17	Video	HDMI Input
TX 18	Video	HDMI Input
TX 19	Video	HDMI Input
TX 20	Video	HDMI Input
TX 21	Video	HDMI Input
TX 22	Video	HDMI Input
TX 23	Video	HDMI Input
TX 24	Video	HDMI Input
TX 25	Video	HDMI Input
TX 26	Video	HDMI Input
TX 27	Video	HDMI Input
TX 28	Video	HDMI Input
TX 29	Video	HDMI Input
TX 30	Video	HDMI Input
TX 31	Video	HDMI Input
TX 32	Video	HDMI Input

HDMI Output Devices


Device	Name	Location	Connections
XBOX One	HDMI Out	Master	Binary MoIP Controller 2->TX 1
Home Controller HC800	HDMI (Audio/Video)	Master	
Laptop PC	AV Out	Master	Binary MoIP Controller 2->TX 2
HouseLogix PC and NVR Control	Output	HouseLogix Test	

Select the source, and drag it to the correct HDMI out device.

Bind the Tx to the correct source.

4. Bind the Rx next.

See example:



FINISHING UP

1. Refresh the Composer and Navigators once all transmitters have been bound.

See example:

