

## PRODUCT OVERVIEW

Insert the thread-locking power connector into the power input on the device (marked 12V 2A) and tighten by turning clockwise. Review *Important Safety Instructions* prior to applying voltage.

## CONTENTS

- 1x Power Supply
- 1x 12VDC Label
- 1x Power Cord

## SPECIFICATIONS

Mechanical	
Input Voltage	AC100V - 240V
Frequency Rated	50 - 60Hz
Input Rated Current	0.8A RMS Max
Leakage Current `	<0.25mA
Input Power (no load)	<0.3W Max (CEC Compliant)
Output Voltage	12VDC $\pm$ 5%
Output Max. Current	2A
Line Regulation	$\pm$ 1%
Short circuit Protection	Output shutdown and auto restart
Certifications and Compliance	UL/CUL, FCC, CE, RCM, R-MEPS, GS, CB, RoHS Compliant
Operating Temperature	0° - 40°C
Storage Temperate	-10° - 70°C
Humidity	Operating 20% - 80%   Storage: 10% - 90%
Dimensions (LxWxH)	80.6 x 50 x 31 mm

## IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire or electric shock, read and follow all instructions and warnings in this manual. Keep this manual for future reference.

1. Do not expose this apparatus to rain or moisture. Do not expose this equipment to dripping or splashing, and ensure that no objects filled with liquids, such as vases, are placed on the equipment. Do not use this apparatus near water.
2. Do not remove cover.
3. Clean only with a dry cloth.
4. Do not block any ventilation openings. Install according to manufacturer's instructions.
5. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
6. Do not override the safety purpose of the polarized or grounding plug. A polarized plug has two blades, one of which is wider than the other. A grounding plug has two matching blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
7. Protect the power cord from being walked on or pinched, particularly at the plug end and where the power cord is attached to the apparatus.
8. Only use attachments and accessories specified by the manufacturer.
9. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, the apparatus does not operate normally, or it has been dropped.
10. To completely disconnect this equipment from power, disconnect the power supply cord from the power outlet.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



# BINARY

Tech Support: (866) 838-5052

Rev: 150821-1300 © 2015 Binary