



HzMMB

INSTALLATION GUIDE

Picture perfect sound.®

Questions?

Call Customer Service

1.888.213.5015

Mon-Fri 8am-6pm EST



Visit us online for product support, guides and videos

www.leonspeakers.com/support



HzMMB : Horizon MatchMount Bracket

Leon's Horizon MatchMount Bracket can be used to mount your Leon Horizon speaker directly to the wall, above or below any TV. This versatile bracket offers multiple points of adjustment for perfect fit, every time.



----- Completed Install -----




Bonded Washer

4x



Wood Screw

4x



Drywall Anchor

4x



Foam Tape

1x



Hex Key

1x





Bracket

1x

Bracket Hardware


*Not to scale



Parts List


*Not to scale

For assistance, call: 1.888.213.5015 | Mon-Fri 8am-6pm EST




Mount **TV** level to wall
and draw **Guide Line** level with TV edge*

Top or **Bottom** dependent on speaker position



Draw a second **Mount Line** 2.5" from **Guide Line**
Find **Center** of TV and **Mark** on **Mount Line**

Above or **Below** dependent on speaker position




Align and center top edge of **Bracket**
with **Mount Line**

Bracket can be secured temporarily with a centered screw



Bracket
1x



Secure **Bracket** to wall using **Bonded Washers** with **Wood Screws** or **Drywall Anchors**

*Minimum of 4 connections recommended

**Connection locations may vary




Bonded Washer
4x



Wood Screw
4x




Drywall Anchor
4x




Measure depth from face of TV to the Wall and adjust speaker **Mounting Bolts** to match

Mounting Bolts come pre-installed




Side View

Hang speaker by securing **Top Mounting Bolts**
in **Mounting Plates**



Adjust **Mounting Bolts** to align
Speaker flush with TV



Bottom Mounting Bolts can adjust speaker tilt
Front of speaker aligned with front of TV



Side View


Adjust **Lock Nuts** to secure assembly

Lock Nuts come pre-installed



Use **Height Screws**
to adjust vertical alignment*

*Can be done with or without Speaker mounted
Speaker should be flush with edge of TV



Ensure all **Connections** are secure
and connect **Wiring** to **Speaker**

Ensure flush TV/Speaker alignment before tightening



715 W. Ellsworth Road Ann Arbor, Michigan 48108 | 1.888.213.5015 | www.leonspeakers.com

Picture perfect sound.®