

The WattBox Trigger provides users with an easy way to cycle power on any or all of the outlets on a WB-IP device.


Package Contents

- WattBox Trigger (normally open, momentary closed) switch with adhesive backing
- Capacitor (buffers the system against stray signals that create a false trigger)

Installation

If your WattBox unit has a service tag (S/T) that ends with the letter “A,” attach the leads from the included capacitor to the leads from the trigger.

Position the switch in the desired location, then connect to the “REMOTE TRIGGER” port on the WattBox using the phoenix connector included with the IP device. Then log into the WB-IP interface to enable the trigger port and select which outlets to power cycle.



2 Year Warranty

This WattBox™ product has a 2-Year Limited Warranty. The warranty includes parts and labor repairs on all components found to be defective in material or workmanship under normal conditions of use. This warranty shall not apply to products which have been abused, modified, disassembled or improperly installed. Products to be repaired under this warranty must be returned to WattBox or a designated service center with prior notification and an assigned return authorization number (RA).

Technical Support

Phone: 866.838.5052

Email: TechSupport@WattBoxPower.com



160922-1249