

Notes

- Screen controls located on panel at left end of the case
- Power cord located on panel at left end of the case

