

Notes:

- Screen controls located on panel at left end of the case
- Power cord located at the rear of case on the left end

