

ATTENTION, WIRELESS SETUP INFORMATION

Device will ALWAYS connect via wired connection when connected to an active network switch port, and Wi-Fi capabilities are deactivated while the device is wired to the network.

When connecting the device wirelessly, DO NOT claim in OvrC until you have the device connected wirelessly.

To ACTIVATE WIRELESS:

- a) While still wired, access the wireless configuration page by accessing the device IP from a web browser.
- b) On the configuration page, ENABLE wireless, scan for available SSIDs, and choose your wireless network, following the prompts for each step.
- c) Once complete, you will be prompted to REMOVE the WIRED CONNECTION. This will activate the device's Wi-Fi capabilities and turn off the wired capabilities.

At this point, the device's "Power/Network" LED will change from SOLID AMBER to BLINKING GREEN while connecting to Wi-Fi and finally to SOLID GREEN, indicating a successful wireless connection.

